


PERF-FORM OIL FILTER CANISTER INSTALLATION INSTRUCTIONS:

Canister can be mounted in any position. For best cooling, mount in air flow out of the way of moving parts.



Mount securely.
Check for leaks.

Return oil line
from the engine.

DESIGNED TO USE PERF-FORM HD-1 DROP-IN FILTER ONLY.

CAUTION: Turning or removing canister fittings may damage canister threads. When using the HD-CB mounting bracket, install the bracket to the bottom side of canister mounting lug (opposite cap side).